



Sure Klean®

CLEANING & PROTECTIVE TREATMENTS

600

Sure Klean® 600 is an acidic cleaner for brick, tile and concrete surfaces. Sure Klean® 600 dissolves mortar smears and construction dirt quickly, leaving the masonry clean and uniform with no acid burning or streaking.

TYPICAL TECHNICAL DATA

| | |
|-------------------------|--|
| FORM | Clear, slight amber liquid Pungent odor |
| SPECIFIC GRAVITY | 1.130 |
| pH | 0.28 @ 1:4 dilution 0.56 @ 1:12 dilution |
| WT/GAL | 9.4 lbs |
| FREEZE POINT | <-22° F (<-30° C) |
| SHELF LIFE | 3 years in tightly sealed, unopened container |

REGULATORY COMPLIANCE

VOC Compliance

Sure Klean® 600 is compliant with all national, state and district VOC regulations.

SAFETY INFORMATION

Always read full label and SDS for precautionary instructions before use. Use appropriate safety equipment and job site controls during application and handling.

24-Hour Emergency Information:
INFOTRAC at 800-535-5053

ADVANTAGES

- The No. 1-selling proprietary cleaner for new masonry.
- Proven effective through years of use.
- Recommended by many brick, tile and mortar manufacturers.
- Supplied in concentrate for easy on-site dilution.
- Safer than muriatic acid for new masonry surfaces.

- Removes efflorescence on bricks, new concrete and new stone construction.
- Fast and easy to apply – use with cold water rinse.
- Special wetting agents let larger masonry surfaces be cleaned at one time, eliminating streaking.

Limitations

- May not be suitable for cleaning buff-colored brick and brick, stone or tile with manganese or other metallic additives. See product literature on Sure Klean® Vana Trol®.
- Not suitable for cleaning polished or certain glazed surfaces. Always test to ensure suitability.
- Repeated applications may leave a detergent residue. Always prewet to reduce potential for detergent residue. Rinse thoroughly. Do not apply more than twice.
- Not effective for removing atmospheric dirt and black carbon stains. Use the appropriate Sure Klean® restoration cleaner to remove atmospheric staining from older masonry surfaces.
- May damage exposed low-E glass treatments; acrylic and polycarbonate sheet glazing; and glazing with surface-applied reflective, metallic or other synthetic coatings and films. Modern soft coat or hard coat low-E glass is not intended to be on the external face of the glass and should not be exposed to or adversely affected by proper cleaning. Always test for adverse effects prior to overall application. If testing is not feasible or indicates adverse effects, such substrates must be protected.

PREPARATION

Clean masonry before installing non-masonry materials such as windows, doors, finished flooring, metal fixtures, hardware, light fixtures, roofing materials, etc. that the cleaner could harm. If cleaning is to be completed after installation of non-masonry materials not intended for treatment or exposure to Sure Klean® 600, test all substrates not intended to be treated with Sure Klean® 600 before full scale application. If testing is not feasible or indicates adverse effects, protect substrates from

Product Data Sheet

Sure Klean® 600

product splash, residue, wind drift and fumes with Sure Klean® Strippable Masking or polyethylene prior to application.

All caulking and sealant materials should be in place and thoroughly cured before cleaning.

When applying to the exteriors of occupied buildings, make sure all windows, exterior intake and air conditioning vents are covered and air handling equipment is shut down during application.

Construction soiling and mortar residues on new brick and tile surfaces clean most effectively if the cleaning is done within 14–28 days of installation. Mortar and grout smears left on the surface longer result in a more difficult clean down and may cause undesirable results. Cleaning high-strength mortar/grout within seven days improves results.

| Recommended for these substrates. Always test. Coverage is in sq.ft./m. per gallon of concentrate. | | | |
|--|------------------------|------|---------------------------------|
| Substrate | Type | Use? | Coverage |
| Architectural Concrete Block♦ | Burnished | no | 300–400 sq.ft. 28–37 sq.m. |
| | Smooth | yes | |
| | Split-faced | yes | |
| | Ribbed | yes | |
| Concrete♦ | Brick | yes | 600–1100 sq.ft. 56–102 sq.m. |
| | Tile | yes | |
| | Precast Panels | yes | |
| | Pavers | yes | |
| | Cast-in-place | yes | |
| Fired Clay | Brick | yes | 500–900 sq.ft. 46–84 sq.m. |
| | Tile | yes | |
| | Terra Cotta (unglazed) | yes | |
| | Pavers | yes | |
| Marble, Travertine, Limestone | Polished | no | N/A |
| | Unpolished | no | N/A |
| Granite | Polished | no | N/A |
| | Unpolished | yes | 600–1200 sq.ft. 56–111 sq.m. |
| Sandstone | Unpolished | yes | 600–900 sq.ft. 56–84 sq.m. |
| Slate | Unpolished | yes | 600–1100 sq.ft. 56–102 sq.m. |
| ♦Repeated applications may damage surfaces. Sure Klean® Custom Masonry Cleaner is a more appropriate product. Always test to ensure desired results. Coverage estimates depend on surface texture and porosity. | | | |

The presence of excessive moisture in the wall contributes to efflorescence and other staining. Always protect open wall cavities from rain during construction.

When working over traffic, clean when traffic is at a minimum. Protect or divert traffic if necessary.

Surface and Air Temperatures

For best results, clean when air and masonry surface temperatures are 40° F (4° C) or above. To avoid harming masonry, do not clean when temperatures are below freezing or will be overnight. If freezing conditions existed before application, let the masonry thaw.

Equipment

Apply with low-pressure (50 psi max) spray or densely-packed, soft-fibered masonry-washing brush. Do not atomize. Do not apply with pressure spray over 50 psi. Such application will drive the chemicals deep into the surface, making complete rinse difficult. Test spray equipment for compatibility and to avoid discoloration.

Rinse with enough water and pressure to flush spent cleaner and dissolved soiling from the masonry surface and surface pores without damage. Inadequate rinsing leaves residues which may stain the cleaned surface.

Masonry-washing equipment generating 400–1000 psi with a water flow rate of 6–8 gallons per minute is the best water/pressure combination for rinsing porous masonry. Use a 15–45° fan spray tip. Heated water (150–180° F; 65–82° C) may improve cleaning efficiency. Use adjustable equipment for reducing water flow-rates and rinsing pressure as needed for sensitive surfaces.

Rinsing pressures greater than 1000 psi and fan spray tips smaller than 15° may permanently damage sensitive masonry. Water flow-rates less than 6 gallons per minute may reduce cleaning productivity and contribute to uneven cleaning results.

Storage and Handling

Transport and store in a cool, dry place with adequate ventilation. Always seal container after dispensing. Do not alter or mix with other chemicals. Published shelf life assumes upright storage of factory-sealed container in a dry place. Maintain temperatures of 45–100° F (7–38° C). Do not double stack pallets. Dispose of unused product and container in accordance with local, state and federal regulations.



Product Data Sheet

Sure Klean® 600

APPLICATION

Read “Preparation” and the Safety Data Sheet before use.

ALWAYS TEST a small area (minimum 4-ft x 4-ft) of each surface to confirm suitability and desired results before beginning overall application. Test each type of masonry and each type of stain. Test with the same equipment, recommended surface preparation and application procedures planned for general application. Let test area dry 3–7 days before inspection and approval. Make the test panel available for comparison throughout the cleaning project.

If test panel indicates metallic discoloration, or if stains are present before testing, refer to the Metallic Discolorations section later in this document.

Dilution

Dilute Sure Klean® 600 with 4–12 parts clean water to one part concentrate, based on test results. Always pour cold water into empty bucket first, then carefully add product. Never use hot water. Handle in high-density polyethylene or polypropylene containers only. No metal. Acidic materials and fumes attack metal.

Typical Coverage Rates

Reference the substrate chart in this document. The coverage rate chart assumes an average coverage rate of 100 square feet per gallon of prepared cleaner.

When calculating the volume of cleaner required for porous, textured surfaces, assume 50 square feet per gallon of prepared cleaner.

For dense, smooth surfaces, assume up to 150 square feet per gallon of prepared cleaner.

Application Instructions

Test thoroughly before general cleaning. Provide adequate ventilation. **CAUTION:** Multiple applications may lighten the mortar color.

Exterior Surfaces

1. Working from the bottom to the top, thoroughly prewet a large area with fresh water.
2. Apply the diluted solution freely from the bottom of the work area to the top.
3. Let cleaning solution stay on the wall for 3 to 5 minutes. Do not let cleaner dry into the masonry. This may leave residue or stains. Fresh water rinse the surfaces below areas being cleaned to prevent streaking.

4. Reapply cleaner and scrape off heavy buildup of excess mortar using a wooden scraper or piece of brick. Take care not to harm the masonry surface.
5. Working from the bottom of the work area to the top, rinse thoroughly with clean water, removing all cleaning compound, free sand, loose material and debris.
6. Reapply as needed following steps 1–5.

Interior Surfaces

Proper ventilation is necessary. Follow exterior application procedures. Use a sponge or soft-fibered brush to rinse thoroughly.

If conditions don't allow enough water for complete rinsing, use a neutralizing rinse following this procedure:

1. Rinse with clean water.
2. Apply neutralizing rinse of 2 ounces baking soda to 1 gallon water.
3. Saturate. Leave solution on surface 3 to 5 minutes.
4. Apply final rinse of clear water.

Cleanup

Clean tools and equipment using fresh water.

Metallic Discolorations

Because of the metallic oxides contained in many colors of brick in use today, green and brown stains can form on the masonry surface. These stains occur when vanadium, manganese or other oxides migrate to the surface of the brick.

Where significant levels of metallic oxides are present in the masonry, an improper dilution of Sure Klean® 600 can contribute to staining.

If the brick shows metallic staining before or after testing, follow these additional steps:

- If stains are light to moderate, test using Sure Klean® 600 at a dilution rate of 8 parts water to 1 part concentrate. After rinsing, let brick weather 10 to 14 days. Minor stains will often disappear if allowed to weather. If results are acceptable, clean using this dilution rate. When cleaning is done, let the wall weather. Spot treat minor stains that have not weathered with Sure Klean® stain removal products.
- If severe stains are apparent before original testing or become a problem at any time during the testing, use Sure Klean® Vana Trol® instead of Sure Klean® 600. Vana Trol® is a cleaning compound formulated specifically to control metallic staining. Follow the procedures outlined in the Vana Trol® product literature. In some

Product Data Sheet

Sure Klean® 600

cases, Vana Trol® will remove vanadium staining. If test panels do not prove effective, test using Sure Klean® 800 Stain Remover and/or Sure Klean® Ferrous Stain Remover.

WARRANTY

The information and recommendations made are based on our own research and the research of others, and are believed to be accurate. However, no guarantee of their accuracy is made because we cannot cover every possible application of our products, nor anticipate every variation encountered in masonry surfaces, job conditions and methods used. The purchasers shall make their own tests to determine the suitability of such products for a particular purpose.

PROSOCO, Inc. warrants this product to be free from defects. **Where permitted by law, PROSOCO makes no other warranties with respect to this product, express or implied, including without limitation the implied warranties of merchantability or fitness for particular purpose.** The purchaser shall be responsible to make his own

tests to determine the suitability of this product for his particular purpose. PROSOCO's liability shall be limited in all events to supplying sufficient product to re-treat the specific areas to which defective product has been applied. Acceptance and use of this product absolves PROSOCO from any other liability, from whatever source, including liability for incidental, consequential or resultant damages whether due to breach of warranty, negligence or strict liability. This warranty may not be modified or extended by representatives of PROSOCO, its distributors or dealers.

CUSTOMER CARE

Factory personnel are available for product, environment and job-safety assistance with no obligation. Call 800-255-4255 and ask for Customer Care – technical support.

Factory-trained representatives are established in principal cities throughout the continental United States. Call Customer Care at 800-255-4255, or visit our web site at prosoco.com, for the name of the PROSOCO representative in your area.

